

# F-150 Gauge Bezel CDC# 450100 & 450101



### **Kit Components:**

□ 3 Place Gauge Bezel

## **Tools Required:**

- □ 90° Probe
- □ 7mm Socket
- □ Nut Driver

www.classicdesignconcepts.com (866) 624-7997 28266 Beck Road, Wixom MI 48393

QW-004-A

#### **Preparing for Gauge Bezel**

1. Open ashtray to access area for center stack bezel removal (it is helpful to use a hook tool to dislodge the first clip).



2. Grasp the center stack bezel and pull outward to dislodge clips.



Note: Use care when pulling on the bezel, the clips are difficult to dislodge. Be careful not to over bend the stack causing a crack.



QW-004-A

- 3. Unplug the wires for the Lighter, Ventilation Controls and the Air Bag Light and set center stack aside.
- 4. Remove the two 7mm head screws that secure the ashtray to the dash panel, save screws for reinstallation.



#### **Installing Gauge Bezel**

- 5. Install gauges into the Bezel and make connections per gauge manufacturers directions.
- 6. With gauges in place, attach the Gauge Bezel to the dash using the two screws removed in step #4.



#### **Reassemble Center Stack**

- 7. Reconnect the wires for the Lighter, Ventilation Controls and the Air Bag Light to the backside of the center stack.
- 8. Align the clips of the center stack with receivers on the dash and snap center stack back into place.

Enjoy your new Classic Design Concepts F-150 Gauge Bezel and if you have any questions or concerns please call 248-624-7997 or email <a href="tech@cdcdetroit.com">tech@cdcdetroit.com</a>

OW-004-A